

# Backpack Harness Installation

NOTE: This backpack harness will only work on those Protec Pro-Pac cases that have hoops stitched into their sides, near the rear of the case. These cases were produced starting in mid-2004. All earlier models of this case will not work.

The harness is attached to the case using three clasps. A fourth clasp runs across the front of the harness and is used to tighten the entire setup against your chest. When installed properly, the case is held low on your back, with the harness in the shape of an inverted "U." To install the harness, follow these directions:

1. Stand your case on the ground, bell down with the accessory pocket facing away from you. This will cause the main handle to be on the left (figure 1).
2. Lay the harness out in the form of an inverted "U." When done properly, the Protec logo should be facing you on the right side. The logo is a small white box with the letters "PT" enclosed (figure 2).
3. Open the large buckle at the top of the harness. Wrap it around the case-end handle and snap it closed. This will serve as the top anchor point for the harness (figure 3).
4. Attach the right and left hand anchors next by inserting the male ends of the two clasps at the bottom right and left of the harness (figure 4) into the hoops on the right and left sides of the case (figure 5).
5. Pull the clasps through the hoops and then snap them together (figure 6). The harness is now ready to be used.
6. Loosen the straps and test the case on your back. Adjust the straps as needed to get a snug fit.
7. Loosen the cross strap on the front of the harness, and then snap it together. Adjust it until it is snug. Use of this strap will increase comfort and reduce strain on the lower back.
8. When properly installed, the case will be held low on your back and will allow full motion of both arms.



figure 1



figure 2

"PT" logo



figure 3



figure 4



figure 5

hoop



figure 6



figure 7